


Quick Installation Guide

PoE Extende



WI-PE31E | WI-PE51E | WI-PE31G | WI-PE51G | WI-PE21E | WI-PE21G

www.wireless-tek.com




1 × PoE Extender



1 × Quick Installation Guide

2.Appearance Overview




Blinking: data on TX/RX


Off: PoE not working

On: PoE working

PoE Indicator









WI-PE31G DIP Switch Descri	ption
	On: The transmission of PoE output ports can be up to 250m, but
Extend	the rate is limited to 10Mbps
Exterio	Off: The transmission of PoE output ports can be up to 100m
	with 100Mbps (WI-PE31G transmission rate can reach 1000Mbps)

LED Indicators	
PWR (Power indicator)	Off: the device is power off or failed
	On: the device power on is normal
Link Indicator	Off: ports link down
	On: ports link up
	Blinking: data on TX/RX
PoE Indicator	Off: PoE not working
	On: PoE working




• WI-P51E




Р	Off: the device is power off or failed
	On: the device power on is normal
Link Indicator	Off: ports link down
	On: ports link up
	Blinking: data on TX/RX
PoE Indicator	Off: PoE not working
	On: PoE working
V	Off: VLAN mode is disable.
	On: VLAN mode is enable.
E	Off: Extend mode is disable
	On: Extend mode is enable

• WI-PE21G




1 x 100/1000Mbps PoE+ output port




1 x 100/1000Mbps PoE+ input port

LED Indicators	Description
Speed	On: The negotiate speed is 1000Mbps
Sheen	Off: The negotiate speed is 10/100Mbps
	On: ports link up
Link	Off: ports link down
	Blinking: data on TX/RX

• WI-PE21E




1 x 100/1000Mbps PoE+ output port




LED Indicators	Description
Speed	On: The negotiate speed is 10/100Mbps
	Off: Ports link down
_ink	On: ports link up
	Off: ports link down
	Blinking: data on TX/RX

3.Installation

Desktop Installation



Wall-mount Installation



4. Network Application

Warranty Card


Networking Solution (illustration for WI–PE31E)

Step 1: Connect the first PoE extender to the PoE port of switch which is compatible with 802.3af/at/bt.(Or connect a DC adapter to power up the first PoE extender)

Step 2: Connect the second PoE extender to the first PoE extender via PoE input port.

Step 3: Connect an IP camera to the second PoE extender via PoE output port.

Note: Recommend no more than 4 units PoE extender in one network.



Username	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Product Model No.	
Purchase Time	
Serial No.	
Dealer Signature	

- If the product defects within three months after purchase, we will provide you a new product of the same model.
- If the product defects within the three-year warranty period, we will provide the professional maintenance service.
- [®] Proof of purchase and a complete product serial number are required to receive any services guaranteed as part of the limited warranty.
- [•] Any other defects that are not caused by workmanship or product quality, such as natural disaster, water damage, extreme thermal or environmental conditions. sticke damaged, warranty card losing will disqualify the product from limited warranty.





Technical Support Cloud Management Company Website

Wireless-Tek Technology Limited

Address: Biaofang Technology Building 402, Bao'an street,

Baoan District,Shenzhen City, Guangdong, China

Website:www.wireless-tek.com

Tel:86-0755-32811290

Email:sales@wireless-tek.com

Technical Support:tech@wireless-tek.com

